

Step 1



Singulate and grasp the transparent accessory bag from the bin

Step 2



Place the accessory bag within the cavity of the cardboard box

Step 3



Push the accessories into the cavity and press the bag to flatten it

Step 4



Retract both the arms to the home pose indicating completion